


ThingSpeak Lab. January 2024

Instructions

Part A: Getting Setup in ThingSpeak and reading/writing to it using the Browser

1. Go to [ThingSpeak](https://thingspeak.com) and click on Get Started for Free
Create new account.




2. Create a new Channel by selecting

Channels,

My Channels,

and then

New Channel



3. Give the channel a name and description (see below) and give Field 1 the name number data and Field 2 Temperature. Click Save Channel. You can also add a location if you wish.

[Private View](#) [Public View](#) [Channel Settings](#) [Sharing](#) [API Keys](#)

Channel Settings

Percentage Complete 50%

Channel ID 698786

Name Lab Test

Description Used for Jan Lab

Field 1 number data



Field 2 Temperature




Field 3




Save Channel

4. Configure Channel visualisation.


Go to Private view. Click on pencil icon (circled in red below) to edit visualisation.



5. Add Widgets. Click add widget, choose lamp.



You can also add a numeric and gauge.



Part B Reading & Writing to ThingSpeak from Browser.

6.

To write data to ThingSpeak we need
Write API Key
Channel ID

To read data from ThingSpeak we need
Read API Key
Channel ID

Go to API Keys for API Read and Write keys and commands

Write API Key

Key: T8LTH3NVBIVOFD81

Generate New Write API Key

Read API Keys

Key: NP1YNTMK89TZF583

Note

Save Note Delete API Key

Add New Read API Key

Help

API keys enable you to write data to a channel or read data from a private channel. API keys are auto-generated when you create a new channel.

API Keys Settings

- Write API Key:** Use this key to write data to a channel. If you feel your key has been compromised, click **Generate New Write API Key**.
- Read API Keys:** Use this key to allow other people to view your private channel feeds and charts. Click **Generate New Read API Key** to generate an additional read key for the channel.
- Note:** Use this field to enter information about channel read keys. For example, add notes to keep track of users with access to your channel.

API Requests

Write a Channel Feed

GET https://api.thingspeak.com/update?api_key=T8LTH3NVBIVOFD81&field1=0

Read a Channel Feed

GET https://api.thingspeak.com/channels/698786/feeds.json?api_key=NP1YNTMK89TZF583

Read a Channel Field


GET https://api.thingspeak.com/channels/698786/fields/1.json?api_key=NP1YNTMK89TZF583

Read Channel Status Updates

GET https://api.thingspeak.com/channels/698786/status.json?api_key=NP1YNTMK89TZF583

Copy the API Request to **Write a Channel Feed**. Remove GET and paste into browser. (Note I changed the value to write from 0 to 20). See below the browser and the ThingSpeak

channel. The response to the browser is 14 as there have been 14 data elements written to the channel.



Copy the Read a Channel Field command and remove GET. Paste into Browser to see the last 2 pieces of data written to it. See below.

```
1 {
2   "channel": {
3     "id": "698786",
4     "name": "Lab Test",
5     "description": "Used for Jan Lab",
6     "latitude": "53.27756",
7     "longitude": "-9.01058",
8     "field1": "number data",
9     "field2": "Temperature",
10    "created_at": "2019-02-08T19:28:14Z",
11    "updated_at": "2024-01-23T15:47:51Z",
12    "last_entry_id": 14
13  },
14  "feeds": [
15    {
16      "created_at": "2021-04-20T10:56:57Z",
17      "entry_id": 13,
18      "field1": "1"
19    },
20    {
21      "created_at": "2024-01-23T15:56:55Z",
22      "entry_id": 14,
23      "field1": "20"
24    }
25  ]
26 }
```

You can look at all the commands.


Part B Write to ThingSpeak from ESP32.

7. Install ThingSpeak Library from Mathworks.

Load the Examples/ThingSpeak/ESP32/WriteSingleField

populate secrets.h

Upload code.



8. In this step you will use example WriteMultipleFields and write the number data to Field 1 and temperature data from the DHT11 to Field 2. Integrate the DHT11 code into the WriteMultipleFields example and **set Field 1 to number** and **Field 2 to temp**. (Note you will have to create this variable). Make the status too hot for temperatures greater than 25, too cold for temperatures less than 15 and fine otherwise.






```
// SET THE FIELDS WITH THE VALUES
ThingSpeak.setField(1, number);
ThingSpeak.setField(2, temp);

// figure out the status message
if (temp > 25 ) {
    myStatus = String("Temperature is too high.");
} else if (temp < 15 ) {
    myStatus = String("Temperature is too low.");
} else {
    myStatus = String("Temperature is fine.");
}

// set the status
ThingSpeak.setStatus(myStatus);
// write to the ThingSpeak channel
int x = ThingSpeak.writeFields(myChannelNumber, myWriteAPIKey);
if (x == 200) {
    Serial.println("Channel update successful.");
} else {
    Serial.println("Problem updating channel. HTTP error code " + String(x));
}

16:31:34.226 -> temp:18.00Channel update successful.
16:31:54.907 -> temp:18.00Channel update successful.
16:32:15.623 -> temp:18.00Channel update successful.
16:32:36.278 -> temp:18.00Channel update successful.
16:32:57.085 -> temp:18.00Channel update successful.
```

Last entry: less than a minute ago
 Entries: 176




9.

**Part C Integrate writing temperature to ThingSpeak with Temperature Server Example.
Add the ThingSpeak chart to your Webpage.**

10. Download the Folder from ThingSpeak Code For Lab from Moodle->ESP32Labs & Resources.

Open the .ino file and add your Wifi details. Upload the code. It should serve the following Webpage.



To this file you will integrate the code to write to ThingSpeak.

Add the secrets.h file to the folder.

Add all the necessary code from the WriteMultipleFields you did in Part B.

This will take care with your coding.

Note: ensure you update ThingSpeak no more frequently than every 20s.

See code snippets below.

Setup the time period with `REPORTING_PERIOD_MS` and the variable used to measure the time periods `tsLastReport`.

Put all ThingSpeak update code inside the if statement

```
30 #define REPORTING_PERIOD_MS 20000 // report to ThingSpeak every 20s
31
40 uint32_t tsLastReport = 0; //4 byte unsigned int to to time ThingSpeak 20s
41
141 }
142 if (millis() - tsLastReport > REPORTING_PERIOD_MS) {
143     // set the status
144     ThingSpeak.setStatus(myStatus);
145 }
158 }
159 tsLastReport = millis(); //update the time stamp
160
161 //delay(20000); // Wait 20 seconds to update the channel again
162 }
```

To incorporate the Thingspeak chart onto your webpage. Make the channel public. See below.

Lab Test

Channel ID: **698786**

Author: **tashita**

Access: Private

Used for Jan Lab

Private View

Public View

Channel Settings

Sharing

API Keys

Data Impo

Channel Sharing Settings

- ☐ Keep channel view private
- ☒ Share channel view with everyone
- ☐ Share channel view only with the following users:

Email Address

Enter email here

Add User

Copy the iframe from Field 2

The screenshot shows the Thingspeak web interface. At the top, there's a navigation bar with 'Developer', 'Support', 'Commercial Use', and 'How to Buy'. Below this, there are tabs for 'MATLAB Analysis' and 'MATLAB Visualize'. The main content area displays a chart titled 'Lab Test' with 'Temperature' on the y-axis and 'Date' on the x-axis. The chart shows a single data point at 18. A red arrow points from the 'Field 2 Chart' tab to a pop-up window titled 'Field 2 Chart IFrame'. The pop-up window contains the following code snippet: `<iframe width="450" height="260" style="border: 1px solid #ccc;" src="https://thingspeak.com/channels/225409/charts/4?bgcolor=%23ffffff&color=%23000000" />`

Copy it into your webpage in homepage.h

```
41 th, td {
42   font-size: 25px;
43   padding: 8px;
44   text-align: left;
45   border-bottom: 1px solid #ddd;
46 }
47 </style>
48 </head>
49 <body>
50   <div class="flex-Container">
51     <h1> Temperature Example Website </h1>
52     <h2> My ThingSpeak Chart</h2>
53     <iframe width="450" height="260" style="border: 1px solid #ccc;" src="https://thingspeak.com/channels/225409/charts/4?bgcolor=%23ffffff&color=%23000000" />
54   </div>
55   <p>Welcome to my website displaying the temperature in ATU</p>
56 </body>
```


You should get a webpage something like below:

